

**DISTRICT OF SECHELT
SANITARY SEWER LINE INSTALLATION
(from the lot line to the house)**

1. Install the sewer line from the house to the sewer main at the property line connection **but do not make the house connection.**
2. Bed sewer line on sand at a minimum depth of 2'0" or if under the driveway 3'0".
3. If the line is installed under the driveway, you **must** use Schedule 40 D.W.V. pipe. **NOTE: Celacor is not acceptable in this location.**
4. **Call for inspection.** You must have a Static test at this time and there should be sufficient sand on site to cover the line with a minimum of 12" of sand.
5. Do not cover the line with sand until the Static test is complete.
6. You may now disconnect your house from the Septic Tank and connect to the sewer system. Place a T.Y. fitting with a clean out at the house.
7. Have your septic tank pumped out. Punch holes in the bottom.
8. **Call for inspection.**
9. Fill the septic tank with sand.
10. **Call for inspection.**